



Quick Start Guide

EK-H4

SENSIRION
THE SENSOR COMPANY

EK-H4 operation with PC


For displaying and logging of data

1 Install viewer software

- Go to www.sensirion.com/EK-H4
- Download & Install «Viewer Software»
- Download & Install «USB Com Port Bridge»


2 Connect EK-H4 Box to PC with the USB cable

If the display of the EK-H4 Box remains black, try installing the «USB Com Port Bridge» again (see step 1). The EK-H4 Box is powered via the USB port of the computer.



3 Connect sensor to the EK-H4 Box


Connect sensor cable to the EK-H4 Box



Connect Sensors to the cable, see image below to learn about the correct sensor orientation

Option 1

FPCB connector





Option 2

PCB connector



4 Open EK-H4 viewer software

- Click on the start button
- Data is now recorded and displayed
- For more information see EK-H4 datasheet




EK-H4 stand-alone operation

For displaying data


1 Power the EK-H4 Box

Connect the power adapter to a power socket.



2 Connect sensor to the EK-H4


Connect sensor cable to the EK-H4 Box



Connect Sensors to the sensor cable, see image below to learn about the correct sensor orientation

Option 1

FPCB connector




Option 2

PCB connector



3 Read sensor data from the EK-H4 display

Sensor data is displayed on the EK-H4 display. The two buttons on the front side of the EK-H4 Box can be used to cycle through different sensors and views.



Thank you for your interest in our digital humidity and temperature sensor series.

For more information, please visit www.sensirion.com/humidity or contact our technical customer support team:

SENSIRION AG

Laubisruetistrasse 50

8712 Staefa

Switzerland

Phone + 41 44 306 40 00

info@sensirion.com

www.sensirion.com